

## NOTES:

- 1. LINE UPGRADES AND LINE TERMINAL UPGRADE WOULD BE DIRECT ASSIGNED.
- 2. LINE UPGRADES AND LINE TERMINAL UPGRADES WOULD BE DIRECT ASSIGNED
- 3. UPGRADES NOT SHOWN AS DIRECT ASSIGNED AT OR BEYOND NETWORK SUBSTATIONS #1 AND #2 WOULD BE CONSIDERED NETWORK UPGRADES.
- ALL COMMUNICATION, CONTROL AND PROTECTION EQUIPMENT ADDITIONS AND UPGRADES REQUIRED AT AND FOR THE DIRECT ASSIGNED FACILITIES ARE ALSO DIRECT ASSIGNED.
- 5. ALL COMMUNICATION, CONTROL AND PROTECTION EQUIPMENT ADDITIONS AND UPGRADES BEYOND THE DIRECT ASSIGNED FACILITIES WILL BE DIRECTLY ASSIGNED THE INCREMENTAL COST OF EQUIPMENT REQUIRED ONLY FOR THE INTERCONNECTION OF THE GENERATOR. UPGRADE COSTS ASSOCIATED WITH MAINTAINING EXISTING OR ADDING NEW NETWORK CAPABILITY WILL BE CONSIDERED NETWORK UPGRADES.

BONNEVILLE POWER ADMINISTRATION

GENERATOR INTERCONNECTION DIRECT ASSIGNMENT GUIDELINES

W/TOC/PRD/GENERATORDIRECTASSIGN.SKF